

096140-0030 Fuel Pump Transfer Pump Technical File

SKU1: G1B90961400030

SKU2: X10000961400030



096140-0030 Fuel Pump Transfer Pump Technical File**content**

1. 096140-0030 Fuel Pump Transfer Pump Introduction	2
1.1. 096140-0030 Fuel Pump Transfer Pump Basic Information.....	2
1.2. 096140-0030 Fuel Pump Transfer Pump Common Part Number.....	2
1.3. 096140-0030 Fuel Pump Transfer Pump Parameter	2
1.4. 096140-0030 Fuel Pump Transfer Pump Specifications and Dimensions	2
1.5. 096140-0030 Fuel Pump Transfer Pump Quality Control	3
1.6. 096140-0030 Fuel Pump Transfer Pump Customized Service.....	3
1.7. 096140-0030 Fuel Pump Transfer Pump Packing List and Package Size.....	4
1.8. 096140-0030 Fuel Pump Transfer Pump Testing Standard and Certificate	5
1.9. 096140-0030 Fuel Pump Transfer Pump Warranty Instructions	6
1.10. 096140-0030 Fuel Pump Transfer Pump Manufacturer.....	7
2. 096140-0030 Fuel Pump Transfer Pump Technical Support	7
2.1. 096140-0030 Fuel Pump Transfer Pump Part Number Location.....	7
2.2. 096140-0030 Fuel Pump Transfer Pump Installation.....	7
2.3. 096140-0030 Fuel Pump Transfer Pump Reasons for Not Working Normally.....	8
2.4. 096140-0030 Fuel Pump Transfer Pump Causes of Being Damaged.....	8
2.5. 096140-0030 Fuel Pump Transfer Pump Technical Support Obtaining Methods.....	8
3. 096140-0030 Fuel Pump Transfer Pump Purchase and Delivery	9
3.1. 096140-0030 Fuel Pump Transfer Pump Purchase Payment Term	9
3.2. 096140-0030 Fuel Pump Transfer Pump Main Sales Markets.....	9
3.3. 096140-0030 Fuel Pump Transfer Pump Declaration Requirements	9
3.4. 096140-0030 Fuel Pump Transfer Pump Shipping Ways.....	9
3.5. 096140-0030 Fuel Pump Transfer Pump Lead time	9
3.6. 096140-0030 Fuel Pump Transfer Pump Logistics Time for Destination Out of China's Areas....	9
3.7. 096140-0030 Fuel Pump Transfer Pump Packing.....	10
4. 096140-0030 Fuel Pump Transfer Pump Storage Standard	11
5. Company Information.....	12
5.1. Company Introduction	12
5.2. Sales-men's Contact Information	13
6. Copyright Statement.....	13

096140-0030 Fuel Pump Transfer Pump Technical File

1. 096140-0030 Fuel Pump Transfer Pump Introduction

1.1. 096140-0030 Fuel Pump Transfer Pump Basic Information

Title	096140-0030 Fuel Pump Transfer Pump	Quality
SKU1	G1B90961400030	China Made New
SKU2	X10000961400030	China Made New

1.2. 096140-0030 Fuel Pump Transfer Pump Common Part Number

(1) Fuel Pump Transfer Pump Exchange Information

Fuel Pump Transfer Pump Part Number	Common Part Number
096140-0030	/

(2) Fuel Pump Transfer Pump Application Information

Fuel Pump Model	OE Number	For Car Model	Engine Number
096000-0590	22100-54180	/	/
096000-0600	22100-54190	/	/
096000-0640	22100-54230	TOYOTA	L
096000-0652	22100-54240	TOYOTA	L
096000-0660	/	YAMAHA	721
096000-0710	/	YAMAHA	729
096000-0720	22100-64050	TOYOTA	1C
096000-0823	/	TOYOTA	TOYOTA
096000-0830	22100-64130	TOYOTA	1C
096000-0840	22100-64140	TOYOTA	1C
096000-0850	22100-21910	TICO	2J-T
096000-0870	22100-58200	TOYOTA	3B
096000-0930	/	TOYOTA	B
096000-0941	22100-58210	TOYOTA	B
096000-1000	22100-64150	TOYOTA	1C-L

(3) Fuel Pump Transfer Pump Part Number Common Writing

096140-0030

1.3. 096140-0030 Fuel Pump Transfer Pump Parameter

Adaptation System: Common Rail System

Fuel Pump Transfer Pump Series: /

Fuel Pump Transfer Pump Type: High Pressure Common Rail Fuel Pump Transfer Pump

1.4. 096140-0030 Fuel Pump Transfer Pump Specifications and Dimensions

Fuel Pump Transfer Pump Size: 15cm* 10cm *8cm

Fuel Pump Transfer Pump Net Weight: 100g
Fuel Pump Transfer Pump Gross Weight: 230g
Fuel Pump Transfer Pump Quality: China Made New
Fuel Pump Transfer Pump Package Size: 13cm*11 cm *3 cm
Fuel Pump Transfer Pump MOQ: 1 Pieces

1.5. 096140-0030 Fuel Pump Transfer Pump Quality Control

(1) Fuel Pump Transfer Pump Testing

All fuel pump transfer pump spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

(2) Fuel Pump Transfer Pump Assembling


For the quality control of the fuel pump transfer pump production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such as fuel pump transfer pump stroke test, fuel pump transfer pump fatigue spring test.

(3) Fuel Pump Transfer Pump Inspection

The factory inspection of the fuel pump transfer pump is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel pump transfer pump for more than three times for factory inspection, and the fuel pump transfer pump installation testing environment are progressed in dust-free workshop.

1.6. 096140-0030 Fuel Pump Transfer Pump Customized Service

(1) **Fuel Pump Transfer Pump's Customized Service Coverage:** Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, fuel pump transfer pump internal packaging, fuel pump transfer pump external packaging and labels customized, etc.

/	
Fuel Pump Transfer Pump House Lettering	White Label

(2) Fuel Pump Transfer Pump's Customized Service Requirements:

The quantity of customized fuel pump transfer pumps shall not be less than 10 pieces.






The quantity of customized fuel pump transfer pump packages shall not be less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

⚠ **Once the customized fuel pump transfer pump is sold, it cannot be returned or exchanged if there is no quality problem.**

1.7. 096140-0030 Fuel Pump Transfer Pump Packing List and Package Size

(1) Fuel Pump Transfer Pump Spare Parts List

No.	1	2	3
Image			
Name	Fuel pump transfer pump assy	White bubble bag	White anti-rust bag
Description	Fuel pump transfer pump assy number: 096140-0030	Prevent fuel pump transfer pumps from being damaged by external forces	Prevent fuel pump transfer pumps from rusting
No.	4	5	6
Image			/
Name	Desiccant	Fuel pump transfer pump packaging box	/
Description	Prevent plunger from rusting; absorb moisture	Place the fuel pump transfer pump and fuel pump transfer pump accessories	/

⚠ Minors are forbidden to use the fuel pump transfer pump assembly, O-ring, nozzle protective cover, fuel fuel pump transfer pump housing protective cover, oil return protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

⚠ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose them properly after using.

⚠ The fuel pump transfer pump and the installation parts should be coated with appropriate sealing oil during installation.

(2) Fuel Pump Transfer Pump Box Size



No.	Name	Fuel Pump Transfer Pump Package Size (cm)
1	Fuel Pump Transfer Pump Box	13*11*3

1.8. 096140-0030 Fuel Pump Transfer Pump Testing Standard and Certificate

Shumatt can provide the factory quality inspection test report of each fuel pump transfer pump to ensure that each delivered fuel pump transfer pump meets the engine performance indicators.

BOTEN		测试报告		4.05.2019 10:42:09	
承办单位: _____ 电话: _____ 地址: _____ 传真: _____ 检测人: _____ 客户地址: _____ 送检单位: _____ 电话: _____ 客户姓名: _____ 传真: _____ 检测项目: _____ 检测名称: 燃油泵 型号-零件号: _____ 检测商: _____					
检测结果					
送检编号: C091002-0511 检测项目: 燃油泵性能					
EGAR TEST:	3.8	4.5	20.0 ± 1.0	✓	
Back:	3.8	4.5	20.0 ± 1.0	✓	
WKPAM:	3.8	4.5	20.0 ± 1.0	✗	
Max:	231.5	231.5 ± 14.4	0.0	✓	
TL:	28.4	28.4 ± 8.5	0.0	✓	
EL:	14.1	15.0 ± 4.8	0.0	✓	
ME:	4.2	4.5 ± 1.8	0.0	✓	
检测日期: _____ 检测地点: _____ 检测人: _____ 检测商: _____					

1.9. 096140-0030 Fuel Pump Transfer Pump Warranty Instructions**(1) Product Warranty Conditions and Instructions**

It is necessary to provide pictures, videos, or test reports detected by the fuel pump transfer pump inspection equipment when the fuel pump transfer pump is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) Fuel Pump Transfer Pump Warranty Coverage

Within 15 days after customer receives the 096140-0030 fuel pump transfer pump, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 096140-0030 fuel pump transfer pump has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the fuel pump transfer pump house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

⚠ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

(3) Fuel Pump Transfer Pump Out of Warranty Coverage

- ① The warranty period has expired.
- ② Fuel pump transfer pump failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- ③ Customer disassembles or repairs the fuel pump transfer pump personally resulting in damage to the fuel pump transfer pump.
- ④ Fuel pump transfer pump damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Fuel pump transfer pump failure or fuel pump transfer pump damage caused by non-fuel pump transfer pump design, technology, manufacturing, quality, and other issues.
- ⑥ Fuel pump transfer pump failure due to system pressure exceeding system approved pressure.
- ⑦ Fuel pump transfer pump failure caused by system voltage exceeding approved voltage.
- ⑧ Fuel pump transfer pump failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- ⑨ Fuel pump transfer pump failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- ⑩ Fuel pump transfer pump failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Fuel pump transfer pump failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Fuel pump transfer pump failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Fuel pump transfer pump failure caused by not complying with the intake system fit clearance and

exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the fuel pump transfer pump connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.10. 096140-0030 Fuel Pump Transfer Pump Manufacturer

Fuel Pump Transfer Pump's Manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. 096140-0030 Fuel Pump Transfer Pump Technical Support

2.1. 096140-0030 Fuel Pump Transfer Pump Part Number Location

1) E.g.: See the fuel pump transfer pump part number as follows

No.	Name
A	Bran, logo, coding

2.2. 096140-0030 Fuel Pump Transfer Pump Installation

(1) 096140-0030 Fuel Pump Transfer Pump Installation Precautions:

⚠ The replacement of the fuel pump transfer pump must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.

⚠ Strictly follow the operation manual of replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the fuel pump transfer pump, the fitting clearance of the fuel pump transfer pump connection, the installation angle and tightening torque of the fuel pump transfer pump, the fitting clearance of the intake system, and the fitting clearance of the exhaust system, so that to ensure the service life of the engine and the normal operation of the fuel pump transfer pump.

⚠ When installing the fuel pump transfer pump on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the fuel pump transfer pump, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

⚠ When installing the fuel pump transfer pump on the engine, please carefully check the components related to the installation of the fuel pump transfer pump to ensure they are not deformed, such as the fuel pump transfer pump pressure plate, screw, fuel pump transfer pump rod and other accessories, and install it in strict accordance with the operation steps of the engine maintenance manual.

⚠ It is forbidden to operate the bare fuel pump transfer pump for a long time in an environment with serious dust pollution and corrosion to iron products.

⚠ It is forbidden to operate the bare fuel pump transfer pump for a long time in a strong magnetic field environment.

2.3. 096140-0030 Fuel Pump Transfer Pump Reasons for Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle fuel pump transfer pump fuel supply system is abnormal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel pump transfer pump of the vehicle.
- (5) The long-term placement of the fuel pump transfer pump causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

⚠ Before installing, carefully check whether other components in the common rail system except the fuel pump transfer pump are damaged to prevent the fuel pump transfer pump from not working properly after being replaced.

2.4. 096140-0030 Fuel Pump Transfer Pump Causes of Being Damaged

- (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the fuel pump transfer pump.
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the fuel pump transfer pump, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the fuel pump transfer pump.
- (4) The abrasion of the fuel pump transfer pump produces iron powder and aluminum powder enter the fuel pump transfer pump and cause damage to the fuel pump transfer pump.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel pump transfer pump and causing damage to the fuel pump transfer pump.
- (6) The fuel pump transfer pump is damaged due to replacement or adjustment of the relevant parts of the fuel pump transfer pump. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the fuel pump transfer pump fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long-time working result in damage to the fuel pump transfer pump.
- (8) The fuel pump transfer pump will be damaged naturally at the end of its working life.
- (9) The fuel pump transfer pump is magnetized (fuel pump transfer pump parts' magnetic exceeded) causing the fuel pump transfer pump to not work properly.

⚠ Before replacing the fuel pump transfer pump, please check the engine parts carefully according to the engine maintenance manual to avoid the fuel pump transfer pump being damaged again after replacement.

2.5. 096140-0030 Fuel Pump Transfer Pump Technical Support Obtaining Methods

- (1) Fuel Pump Transfer Pump Technical File , visit <http://shumatt.com> to get the technical file.
- (2) Fuel Pump Transfer Pump Technical Videos

Facebook: Visit <https://www.facebook.com/hison.li> to get the technical videos, constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7ViV_mAfxh_Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit <http://shumatt.com> to get the technical videos.

(3) Fuel Pump Transfer Pump Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <http://shumatt.com> to get the download and installation tutorial

(4) Search The fuel pump transfer pump test data through TruckBook Parts EPC APP.

3. 096140-0030 Fuel Pump Transfer Pump Purchase and Delivery

3.1. 096140-0030 Fuel Pump Transfer Pump Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

⚠ Please contact our salesmen for specific payment information.

3.2. 096140-0030 Fuel Pump Transfer Pump Main Sales Markets

Fuel pump transfer pump main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3. 096140-0030 Fuel Pump Transfer Pump Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 096140-0030 Fuel Pump Transfer Pump Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. 096140-0030 Fuel Pump Transfer Pump Lead time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases)

3.6. 096140-0030 Fuel Pump Transfer Pump Logistics Time for Destination Out of China's Areas

DHL Logistics Time :

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days

Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	/	/	/	/

⚠ The logistics time is for reference only and is subject to the actual arrival.

3.7. 096140-0030 Fuel Pump Transfer Pump Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.1.

International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 2.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

⚠ The packing tray is made of plastic and can be recycled.

⚠ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

⚠ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and

white wrapping protective film to avoid personal injury.



Pic No. 1

Domestic express packaging:

Wrapped with Transparent tape



Pic No. 2

International express packaging:

Wrapped with yellow tape after wrapping
black protective film



Pic No. 3

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4. 096140-0030 Fuel Pump Transfer Pump Storage Standard

(1) Choose a suitable storage place

The warehouse and cargo yard where the fuel pump transfer pump is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

Strict inspections should be carried out when the fuel pump transfer pumps are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash, and other dirt, remove the

rust and do anti-rust treatment in time. Packaged fuel pump transfer pumps must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the fuel pump transfer pumps placed in the room, and the corrosion of the fuel pump transfer pumps is significantly reduced.

Fuel pump transfer pumps must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the fuel pump transfer pump is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the fuel pump transfer pump from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the fuel pump transfer pump package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.



It is forbidden to leave the fuel pump transfer pump exposed in the air for a long time.



It is forbidden to store acids, alkali, salt, and other substances together with the fuel pump transfer pump.



The unpacked fuel pump transfer pump must be rust-proof during secondary storage.

5. Company Information



Office Locations



Global Exhibitions

5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司


English Name: Shenzhen Shumatt Technology Co., Ltd



Mob Phone/WeChat: +86-13410541523





HK Telephone: +852-67653519

 **Telephone:** +86-755-23215133


 **Email:** ruby@shumatt.com

 **Website:** www.shumatt.com

 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

 **Shenzhen Office:** Exit C, Qiao Touxu Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

 **After-sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: [1.9. 096140-0030 Fuel Pump Transfer Pump Warranty Instructions](#))

5.2. Sales-men's Contact Information

No.	Name	WeChat/WhatsApp	Email
1	Ruby	+86-13410541523	ruby@shumatt.com
2	Ivy	+86-18025299821	sales@shumatt.com
3	Rebecca	+86-18025349821	sales01@shumatt.com
4	Janny	+86-18028749821	sales02@shumatt.com
5	Sam	+86-13316859821	Sales8@shumatt.com
6	Natalie	+86- 18938945856	sales15@shumatt.com
7	Ada	+86-1342286353	sales5@shumatt.com
8	Hison Li	+86-18318811871	web@shumatt.com
9	Mecca	+86-18938948618	sales11@shumatt.com
10	Eric	+86 18319033618	sales3@shumatt.com
11	Wayne (Joaquín en español)	+86-13316959821	wayne@shumatt.com
12	Sylvia	+86 18312499884	sales6@shumatt.com
Visit http://shumatt.com to obtain the latest information of salesmen			
PS: Shumatt's sales-men's emails are all end with @shumatt.com			

6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds, or videos, etc.) provided in "**096140-0030 Fuel Pump Transfer Pump Technical File**" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "**096140-0030 Fuel Pump Transfer Pump Technical File**" in any way. At the same time, any conditions to spread, re-post, display the contents of "**096140-0030 Fuel Pump**

Transfer Pump Technical File” should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use “096140-0030 Fuel Pump Transfer Pump Technical File” will violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions. All referenced brands are property of their respective owners. This website is not affiliated with them.