

SPURATI

SPADERT

0445120058 Injector CRIN2L Technical File

SALEAN

Stand Strand Stand Stand Stand Strand	de la
1.0445120058 Injector's Introduction	. 2
1.1. 0445120058 Injector's Basic Information	. 2
1.1. 0445120058 Injector's Basic Information 1.2. 0445120058 Injector's Common Part Number	. 2
1.3.0445120058 Injector's Matching Information	. 2
1.4.0445120058 Injector's Parameter	
1.6. 0445120058 Injector's Quality Control	. 3
1.7. 0445120058 Injector's Customized Service 1.8.0445120058 Injector's Packing List and Package Size	. 3
1.8.0445120058 Injector's Packing List and Package Size	. 3
1.9.0445120058 Injector's Testing Standard and Certificate	. 5
1.10.0445120058 Injector's Warranty Instructions	5
1.11.0445120058 Injector's Manufacturer	
2.0445120058 Injector Technical Support	. 6
2.1.0445120058 Injector's Part Number Location	. 6
2.2.0445120058 Injector's Application Scenarios	
2.3.0445120058 Injector's Installation	7
2.4. 0445120058 Injector 's Reasons for Not Working Normally	
2.5. 0445120058 Injector 's Causes of Damage	. 0 8
2.5. 0445120058 Injector 's Causes of Damage 2.6.0445120058 Injector's Technical Support Obtaining Methods	8
3.0445120058 Injector's Purchase and Delivery	9
3.2.0445120058 Injector's Main Sales Markets	
3.3.0445120058 Injector's Declaration Requirements	. ر. م
3.4.0445120058 Injector's Shipping Ways	q
3.5.0445120058 Injector's Lead time	
3.6.0445120058 Injector's Logistics Time for Destination Out of China's Areas	. J
3.7.0445120058 Injector's Packing	
4.0445120058 Injector's Storage Standard	
	11 12
5.41 Company Introduction	
	12 13
6. Copyright Statement	12
show show show show show show show show	ц ^{ар}
- AND CARDER AND CARDER AND CARDER AND CARDER AND CARDER AND CARDER CARDER CARDER CARDER CARDER CARDER CARDER C	19
. 20. 20. 20. 20. 20. 20. 20. 20. 20. 20	10.1
The The Tree Tree Tree Tree The Tree The Tree Tre	
Store	ц ^{ар}
Alter Atte Atte Atte Atte Atte Atte Atte A	

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

0445120058 Injector CRIN2L Technical File

1.0445120058 Injector's Introduction

Aller. - STATION a^{pp} - Aller Aller 1.1. 0445120058 Injector's Basic Information

	injector o Buor	e miermación					
Title	China m	ade new high qu	ality diesel injector 04451	20058 fue	el injecto	r CRIN2L	5
SKU1 S	an san	There - There	G1W20445120058	St. St.	Ser.	Sec.	-93
SKU2							
A STATE AND A STATE	a differ a diffe	and all	the the state of	E set	S	S	С
1.2.0445120058	Injector's Con	nmon Part Num	iber ¹	31	2000	200	- 535

1.2. 0445120058 Injector's Common Part Number

(1) Injector's Exchange Information

(=)		- A A A				
Injector Part Number	Universal Part Number	Re-manufactured Part Number				
0445120058		0 986 435 633				
Ten Ston Ston Ston	the the the the	The The The The				
all all all	all	as the as all as				

(2) Injector's Application Information

Injector Part Number	MERCEDES-BENZ Car Model	MITSUBISHI FUSO TRUCK & BUS CO Car Model
0445120058	ME 356178	ME355793
0 986 435 633	ME 356178	ME355793
all all all	all all all a	e de de de de de de de

(3) Injector's Part Number Common Writing

0445120058, 0 445 120 058, 0445 120 058, 0445120 058, 0 445120058, 0 445120 058, 0 986 435 633

19 C -120 1.3.0445120058 Injector's Matching Information

Vehical brand	Series	Car Model	Engine Model	Production date	Power KW	Horse power	Emission Standards	Manufacturer	Emissions (L)	Cylinder	Power Source V
SPAIRST	SPARANT'S	R.MART SHE	THAT SHELF	ATT SHEAT	1 5783000	57 570200	Status	T SHUDDET	8.500 T 3.19	STATE SHE	

1.4.0445120058 Injector's Parameter Adaptation System: Common Rail System Injector Series: 120 Series Parameter Performance: CRIN2L SPRINT -Stark Matching Accessories: Gasket F 00R J02 175 (7.73*14.36*1.49) Injector Type: Electromagnetic Injector Support System Maximum Pressure: 1,600 Vehicle Configuration Information: MERCEDES-BENZ/MITSUBISHI FUSO TRUCK & BUS CO 1.5.0445120058 Injector's Specifications and Dimensions **Injector Size:** 21.5cm*4 cm *4 cm = 344cm³ (L*W*H=V) Injector Net Weight: 0.55kg - 17 M

Mob/WhatsApp: +86 13410541523 Email : ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Gross Weight: 0.6kg Injector Quality: China Made Brand New Package Size: 28cm*7 cm *7 cm = 1372 cm³ Injector Type: Diesel Common Rail Injector MOQ: 4 Pieces

1.6. 0445120058 Injector's Quality Control

(1) Injector Testing

All injector spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

(2) Injector Assembling

And the quality control of the injector production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such as injector stroke test, injector solenoid valve tightening torque, injector nozzle tightening torque,

ः हैं। इ.स.

(3) Injector Inspection

The factory inspection of the injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel injector for a total of no less than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

1.7. 0445120058 Injector's Customized Service

1999) 1997

(1) Injector's Customized Service: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, injector internal packaging, injector external packaging and labels customized, etc.



(2) Injector's Customized Service Requirements:


The purchased of customized injector are not less than 10 pieces. Customized injector packages no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

A Once the customized fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.

1.8.0445120058 Injector's Packing List and Package Size

(1) Injector Spare Parts List



Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

		01 ,	
Name	Fuel Injector	O-Ring	Gasket F 00R J02 175
Description	Fuel injector part number: 0445120058	Ensure to meet the standard of the sealing performance between the injector and the engine	Made of brass, used to ensure the tight fit between the injector cap end and the engine
No.	5 <u>.</u>	5	6
3000 3000	st ster		State State
Image Stranding Strand	str stell	an an	STRUTT SIR
Name	Nozzle Protective Cover Cap	Injector House Protective Cover Cap	Solenoid Valve Protective Cap
Description	Protect nozzle holes from being polluted and blocked	Protect oil inlet from being polluted and blocked	Protect the solenoid valve body and terminals from being damaged by external forces
No.	7	8	9
Stormer Storm			ite the the the
Image Station Station		art At	51 ⁶³ 51 ⁶⁵
Name	VCI Anti-rust Bag	Bubble Bag	Injector Packing Box
Description	Prevent fuel injector from and a second rusting	Prevent the injector from being damaged by external forces	Place injector and injector accessories

▲ Minors are forbidden to use the fuel injector assembly, O-ring, gasket, nozzle protective cover, fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

• O-ring and gasket are disposable installation accessories, and need to be replaced for


re-installation.

 $\langle p \rangle^{0,2}$

▲ The nozzle protective cover, the injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

▲ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

▲ The injector and the installation parts should be coated with appropriate sealing oil during installation.



Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website : www.shumatt.com $\phi^{(i)}$

ð	No.	Na	me			Ir	jector Pa	ackage S	ize(cm))			1.0
01	1	Inject	or Box					28*7*7					10
	100	-55	-55	-25	- 15	100	100	100	100	-55	15	-25	

1.9.0445120058 Injector's Testing Standard and Certificate

We can provide the factory quality inspection test report of each injector to ensure that each injector delivered meets the engine performance indicators.

30.1	300.	34.		-94 m	-94	84.	39.1	250.1	201	2867	1
BOTEN	测试报告	4.05.2019 10:42:09									
录曲企业:		1111212	and the	57 519-518	ST STOR	57 ⁰ 57 ^{0,007}	st. strate	TT SAINT	SPARSE	CT 578-575	1 ⁹ 3
405:	跑址:		and all the	- A. 1990	and the	- A. 200	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	100	A.S. 19	and all a	1
(4頁)	松潤人:		200	- 1994 - C	2011	201	2011	280.1	250.1	360.1	- 3
WORDE.											
4i8.	送检单位。			at 1	-1	-1	-1	- 1	1	15	$\sim 1^{-1}$
倚真:	客户姓名:		100	17 519-200	576,008 576,008	STRUEDE	571 570-502	SPASSO	NT SPRINT	17 579,505	Q. Y.
林荫报注:			1000	1.00	1.00	- 19 Mar 19 M	and the second	13131	1.200	1990 - Carlos - Carlo	
			20.0	dana -	200	24.6	201	26.1	25.1	26.1	
放 科名标:											
型号-零件号:				1	1	21	TT STAIRT	TT SAUTO	. A.	. e.	20
Man .				1	9	11	8 °	81	81	1	оч т.
		0	272.575	r steart	SPLEE	570,208	Section .		n'i _{SPA} RNI	17 578-578	:
1521161010 : C06000-6511	检测结果		de. i	- Period	- 14 - 1	-let t	261	361	Jac 1	- Jacob	
na wasawa ka	448228 R528.063	800 × 608									
LEAK TEST: 32 Fack: 31	4.5 4.5	20.84"+X V		d	di la	di in	ST. STATOR	R ^I SPACE	TT SPLOT	578.575	25
without 3.0	1473±165 C3		- 18 C	TT STRUTT	TT SPLEE	STRING	9	11. selle	11	್ ಎನ್	9.5
Max7 2013 TU: 2044	218 5±144 03 346±85 03	······ ··· · · · · · · · · · · · · · ·	53. ^{29,0}	- 52 ^{0,0}	- Star	and the second second		- Aller	and the second		1
TL: 28.4 UL: 14.0	102248 02	×	den e	-10				per r	-per t	- Pre-	
VE: 42	45±12 C3	_•_ V									
				A	A	A	de la compañía de la	. A.	A	æ.	10
			1.158	1	9 - 1. ali	e i sali	9 i	11. sefe	11 - L (B)	1	9.7
			679-205	ri Siline	and appendix	ST STOR	STATURE	SALER SALER	TT SPLEE	CT SPRACT	
							560 C	540° °	1947.1	19471.5	
en Lles Lles Lles Lle	6 _ at _ as (2009)95.										
▲ 推移前 □ 重決層			SPREEN	57 578-578	SILITS	ST STORE	TT STATE	STATES	SPLESS	SPR 200	d^{2}
ger and	and and	10 - 30 - 50 A	- ಎನ್	1	11 . A.S.	1 . A.	1.08	11	11	1 . dil	9 C. S.
1			- 10 ⁰⁰⁻¹	- 100° - 1	- Aller	Store -	State -	- 198 ⁹⁰⁰	- 18 ⁰⁰⁻¹⁶		

1.10.0445120058 Injector's Warranty Instructions

(1) . Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector inspection equipment when the injector is abnormal during use as evidence to feed back to the salesman. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) . Injector Warranty Coverage

SHURN C Within 15 days after customer receives the 0445120058 injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0445120058 injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 509,200 months from the date of repairing.

(3) . Injector Out of Warranty Coverage

The warranty period has expired.

NEW T ANTER . 177500 STATE. Injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Customer disassembles or repairs the injector personally resulting in damage to the injector.

1885 C

Injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire). Injector failure or injector damage caused by non-injector design, technology, manufacturing, quality

and the

6 E -

and other issues.

all the Injector failure due to system pressure exceeding system approved pressure.

an star

Injector failure caused by system voltage exceeding approved voltage.

Injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

Injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

Injector failure caused by not following the installation angle specified in the vehicle engine 57.50 512.00 SPLINE 519-553 SASTIN. 33.50° Strang Strang maintenance manual.

Injector failure caused by not following the cleaning requirements specified in the vehicle engine COLOR T. USERT'S 1779CD maintenance manual. and a start of

Injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

Injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.11.0445120058 Injector's Manufacturer

11 May 201

Injector's manufacturer: Shenzhen Shumatt Technology Co., Ltd

2.0445120058 Injector Technical Support

2.1.0445120058 Injector's Part Number Location

1) E.g.: The injector part number see as follows




μ^{gee}	all all	and and and and and
	No.	Name
e de la	AT SHI	brand, logo, part number, series number
	В	nozzle part number
	di sati sa	and a south a south a south as

2.2.0445120058 Injector's Application Scenarios

Common rail system is an oil supply method refers to the diesel oil from the fuel tank sucked out by the gear pump through the oil-water separator and the gear pump to diesel fine filter, high-pressure pump, common rail pipe, and fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injection pressure and the injection process from each other.

- 1995

Mob/WhatsApp: +86 13410541523 Email : ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd



	a a		and p	ic No. 1	h. h. h	1	15. A.
No.	Name	No.	Name	No.	Name	No.	Name
1	Tank	⁵	Common Rail Pressure Sensor	9	Engine Crankshaft Sensor	A	High Pressure Oil
2	Diesel Filter	6,00	Common Rail Pipe	10	Camshaft Sensor	⁵⁹⁷ в 🔅	Low Pressure Oil Circuit
3	High-Pressure Pump	s ⁷	Injector	< 11 	ECU Electronic Control	100	The The
4	Fuel Gear Pump	8	Accelerator Pedal	- Star	all all at	907	1 ²⁰ - 2 ²⁰ - 2 ³

2.3.0445120058 Injector's Installation

SHUMATT

(1) .0445120058 Injector's Installation Precautions:

▲ The replacement of the fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual,

A Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector, the fitting clearance of the fuel injector connection, the installation angle and tightening torque of the injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector.

▲ When installing the fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

Before installing, check whether the fuel injector nozzle gasket has been replaced and installed on the fuel injector.

When installing the fuel injector, apply lubricant between the fuel injector, fuel nozzle sealing gasket and O-ring.

▲ Without replacing new gasket can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the fuel injector and nozzle to break and cause damage to the engine.

▲ When installing the injector on the engine, please carefully check the components related to the installation of the injector, such as the injector pressure plate, screw, injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
▲ It is forbidden to operate the bare injector for a long time in an environment with serious dust pollution and corrosion to iron products.

It is forbidden to operate the bare injector for a long time in a strong magnetic field environment.

2.4. 0445120058 Injector 's Reasons for Not Working Normally

(1) There is air in the oil circuit of the engine fuel system.

(2) Vehicle oil pump oil supply system is not normal.

(3) Engine common rail system oil leakage or pressure limiting valve damage.

(4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel injector of the vehicle.

(5) The long-term placement of the injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

Before installing, carefully check whether other components in the common rail system except the fuel injector are damaged so as to prevent the fuel injector from not working properly after being replaced.

2.5. 0445120058 Injector 's Causes of Damage

(1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the injector. all. 657

(2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities \$30000 all the exceed the standard, etc.

(3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector.

(4) The abrasion of the oil pump produces iron powder and aluminum powder enter the fuel injector and cause damage to the fuel injector.

(5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel injector and causing damage to the fuel injector. ALCONT.

(6) The fuel injector is damaged due to replacement or adjustment of the relevant parts of the fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector fails to meet the original standard.

(7) The engine is overheated and overloaded for a long time working results in damage to the fuel injector.

(8) The injector will be damaged naturally at the end of its working life.

1997 T (9) The injector is magnetized (injector parts' magnetic exceeded) causing the injector to not work properly.

A Before replacing the fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the fuel injector being damaged again after replacement.

-58^{9,5055} 2.6.0445120058 Injector's Technical Support Obtaining Methods

(1) Injector Technical File, visit <u>http://shumatt.com</u> to get the technical file. (2) Injector Technical Videos

Facebook: Visit https://www.facebook.com/hison.li to get the technical videos, constantly follow can get

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

more information. YouTube: https://www.youtube.com/channel/UCByvYBx7VjV mAfxh_Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) Injector Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

 $d^{(k)}$

(4) Search The fuel injector test data through TruckBook Parts EPC APP.

3.0445120058 Injector's Purchase and Delivery

. There are and a there are 3.1.0445120058 Injector's Purchase Payment Term **Payment Terms:** T/T, PayPal, Alipay, WeChat Please contact our salesmen for specific payment information.

3.2.0445120058 Injector's Main Sales Markets

100 Injector main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3.0445120058 Injector's Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc. N. COR

- California

N. 18 3.4.0445120058 Injector's Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by 53¹2¹⁰ customers.

3.5.0445120058 Injector's Lead time

1700 Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

STATE. 1288 C 68⁵⁵ 3.6.0445120058 Injector's Logistics Time for Destination Out of China's Areas

DHL Logistics Time :

and the

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination		Country of Destination	Estimated Arrival Time	
Japan	3 Days	Ste OK Ste	5-7Days	Store Egypt	5-7 Days	
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days	
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days	
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days	
all at	an an	The The The	de d	The The T	all all	

Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days] _
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days	19
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days]
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days	1.80
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days	
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days	
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days	$\delta \zeta_{0}$
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days	
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days	$\varphi_{i}^{(0)}$
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days	
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days	a de la
Kuwait	7-10 Days		· · · · ·			

The logistics time is for reference only , subjects are according to the actual arrival.

3.7.0445120058 Injector's Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.2. **International express packaging:** Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 3.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4,

also, the products can be packaged according to customers' requirements.

The packing tray is made of plastic and can be recycled.

Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.



Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133 Website : www.shumatt.com air i



39.57 Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4.0445120058 Injector's Storage Standard

Pic No. 4

(1) Choose a suitable storage place

The warehouse and cargo yard where the fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkalis, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

Strict inspections should be carried out when the fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injectors must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the fuel injectors placed in the room, and the corrosion 0215 188 C of the fuel injectors is significantly reduced. ages 1 ast." at in

Injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

SALERE SARES After the injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse - alur alur

If the fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

• It is forbidden to leave the injector exposed in the air for a long time. 17700

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

. 19⁵⁵

A It is forbidden to store acids, alkalis, salts and other substances together with the injector.

NOR CL

- 199⁷ -

- The unpacked fuel injector must be rust-proof during secondary storage.
- 5. Company Information

- **Office Locations**
- Global Exhibitions

5.1. Company Introduction Chinese Name: 深圳市舒马特科技有限公司 English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.net

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

STRUMPT STRUMPT

SPERAT

SPAIRST

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

and a start and a

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.10.0445120058</u> Injector Warranty Instructions)

No.	Name	WeChat/WhatsApp	Email	Facebook	YouTube
1	Ruby	+86-13410541523	ruby@shumatt.com	Hison Li	Hison Li
2.5	lvy as from	+86-18025299821	sales@shumatt.com	Ivy Shumatt	Shumatt IVY
3	Rebecca	+86-18025349821	sales01@shumatt.com	Rebecca SHUMATT	SHUMATT Rebecc
4	Janny	+86-18028749821	sales02@shumatt.com	Janny shumatt	Janny Shumatt
5.0	Sam	+86-13316859821	Sales8@shumatt.com	Shumatt Sam	Sam Shumatt
6	Natalie	+86- 18938945856	sales15@shumatt.com	Shumatt Natalie	Lin Natalie
7	Ada	+86-1342286353	sales5@shumatt.com	Shumatt Ada	Ada Shumatt
8	Hison Li	+86-18318811871	web@shumatt.com	Hison Li	Hison Li
9	Mecca	+86-18938948618	sales11@shumatt.com	Shumatt Mecca	Shumatt Mecca
10	Eric	+86 18319033618	sales3@shumatt.com	20.	
11 	Wayne (Joaquín en español)	+86-13316959821	wayne@shumatt.com	shumattwayne	Wayne Shumatt
12	Sylvia	+86 18312499884	sales6@shumatt.com	A. 40	- 1 I.
		Visit http://shumatt.com to ob	otain the latest information of salesme	en	
		PS: Shumatt's sales-men's e	mails are all end with @shumatt.com	14	1.1.1

6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in "**0445120058** Injector CRIN1-14/16 Technical File" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd. without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "**0445120058** Injector CRIN1-14/16 Technical File" in any way. At the same time, any conditions to spread, re-post, display the contents of "**0445120058** Injector CRIN1-14/16 Technical File" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "**0445120058** Injector CRIN1-14/16 Technical File" will violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions.

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd