

**5471860 Fuel Pump K19 Series Technical File**

SKU: Z1K30005471860



**5471860 Fuel Pump K19 Series Technical File****Content**

|                                                                                  |    |
|----------------------------------------------------------------------------------|----|
| 1. 5471860 Fuel Pump Introduction .....                                          | 2  |
| 1.1. 5471860 Fuel Pump Basic Information .....                                   | 2  |
| 1.2. 5471860 Fuel Pump Common Part Number.....                                   | 2  |
| 1.3. 5471860 Fuel Pump Parameter .....                                           | 2  |
| 1.4. 5471860 Fuel Pump Specifications And Dimensions .....                       | 2  |
| 1.5. 5471860 Fuel Pump Quality Control .....                                     | 2  |
| 1.6. 5471860 Fuel Pump Customized Service.....                                   | 3  |
| 1.7. 5471860 Fuel Pump Packing List and Package Size .....                       | 3  |
| 1.8. 5471860 Fuel Pump Testing Standard and Certificate .....                    | 5  |
| 1.9. 5471860 Fuel Pump Warranty Instructions .....                               | 5  |
| 1.10. 5471860 Fuel Pump Manufacturer .....                                       | 6  |
| 2. 5471860 Fuel Pump Technical Support.....                                      | 6  |
| 2.1. 5471860 Fuel Pump Use location .....                                        | 6  |
| 2.2. 5471860 Fuel Pump Installation.....                                         | 7  |
| 2.3. 5471860 Fuel Pump Not Working Normally.....                                 | 8  |
| 2.4. 5471860 Fuel Pump Causes of Being Damaged.....                              | 8  |
| 2.5. 5471860 Fuel Pump Technical Support Obtaining Methods .....                 | 9  |
| 3. 5471860 Fuel Pump Purchase and Delivery .....                                 | 9  |
| 3.1. 5471860 Fuel Pump Purchase Payment Term .....                               | 9  |
| 3.2. 5471860 Fuel Pump Main Sales Markets .....                                  | 9  |
| 3.3. 5471860 Fuel Pump Declaration Requirements .....                            | 9  |
| 3.4. 5471860 Fuel Pump Shipping Ways .....                                       | 9  |
| 3.5. 5471860 Fuel Pump Lead Time.....                                            | 9  |
| 3.6. 5471860 Fuel Pump Logistics Time for Destination Out of China's Areas ..... | 9  |
| 3.7. 5471860 Fuel Pump Packing.....                                              | 10 |
| 4. 5471860 Fuel Pump Storage Standard.....                                       | 11 |
| 5. Company Information .....                                                     | 12 |
| 5.1. Company Introduction.....                                                   | 12 |
| 5.2. Salesmen's Contact Information .....                                        | 13 |
| 6. Copyright Statement.....                                                      | 13 |

**5471860 Fuel Pump K19 Series Technical File****1. 5471860 Fuel Pump Introduction****1.1. 5471860 Fuel Pump Basic Information**

| Title | 5471860 K19 Series Fuel Pump | Quality         |
|-------|------------------------------|-----------------|
| SKU   | Z1K30005471860               | Re-manufactured |

**1.2. 5471860 Fuel Pump Common Part Number****(1) Fuel Pump Exchange Information**

| Fuel Pump Part Number | Car Model | Compatible Number | OE Number |
|-----------------------|-----------|-------------------|-----------|
| 5471860               | /         | 4306515           | 5471860RX |

**(2) Fuel Pump Application Information**

| Vehicle Brand | Car Model | Engine Model | Production Date | Power (KW) | Horse Power | Emission (L) | Cylinder | Power Source (V) |
|---------------|-----------|--------------|-----------------|------------|-------------|--------------|----------|------------------|
| /             | /         | /            | /               | /          | /           | /            | /        | /                |

**(3) Fuel Pump Common Writing**

5471860, 4306515, 5471860RX

**1.3. 5471860 Fuel Pump Parameter**Adaptation System: **Common Rail System**Fuel Pump Series: **K19 Series**Fuel Pump Type: **High Pressure Pump, CCR1600 System****1.4. 5471860 Fuel Pump Specifications And Dimensions**Fuel Pump Size: **28cm \* 30cm \* 31 cm**Fuel Pump Net Weight: **7kg**Fuel Pump Gross Weight: **8kg**Fuel Pump Quality: **Re-manufactured**Fuel Pump Package Size: **30cm \* 32cm \* 33cm**Fuel Pump Type: **High Pressure Pump Fuel Pump**Fuel Pump MOQ: **1 Pieces****1.5. 5471860 Fuel Pump Quality Control****(1) Fuel Pump Testing**

All fuel pumps are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

## (2) Fuel Pump Assembling

For the quality control of the Fuel Pump production and installation process, our company strictly follows the standard product installation data and product installation steps to install.

## (3) Fuel Pump Inspection

The factory inspection of the fuel pumps is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel pumps for more than three times for factory inspection, and the fuel pumps installation testing environment are progressed in dust-free workshop.

### 1.6. 5471860 Fuel Pump Customized Service

**(1) Fuel Pump Customized Service Coverage:** Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, fuel pump internal packaging, fuel pump external packaging and labels customized, etc.



## (2) Fuel Pump Customized Service Requirements:

The quantity of customized fuel pump shall not be less than **10 pieces**.


The quantity of customized fuel pump packages shall not be less than **1000 pieces**.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

⚠ **Once the customized fuel pump is sold, it cannot be returned or exchanged if there are no quality problems.**

### 1.7. 5471860 Fuel Pump Packing List and Package Size

#### (1) Fuel Pump Spare Parts List

| NO.         | 1                                                                                   | 2                                                                                    | 3                                                                                     |
|-------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Picture     |  |  |  |
| Name        | Fuel Pump Assembly                                                                  | Blue Anti-Rust Bag                                                                   | Lining                                                                                |
| Description | Fuel pump part number: 5471860                                                      | Prevent fuel pump from rusting                                                       | Prevent the fuel pump from being damaged by external forces                           |

| NO.         | 4                                                                                 | 5                                                                                  | 6 |
|-------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|---|
| Picture     |  |  | / |
| Name        | Fuel Pump Packaging Box                                                           | Fuel Pump Protective Cover                                                         | / |
| Description | Place the fuel pump and accessories                                               | Protect the fuel pump hole from contamination and blockage                         | / |

⚠ Minors are prohibited from using the fuel pump assembly, O-ring, fuel inlet protective cover, fuel pump shell protective cover, oil return protective cover, VCI anti-rust bag, and bubble bag to avoid personal injury.

⚠ O-rings and repair kits are one-time installation accessories and need to be replaced when installed again.

⚠ Oil inlet protective cover, fuel pump shell protective cover, and oil return protective cover are recyclable accessories and can be reused.

⚠ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

⚠ The fuel pump and the installation part duct must be treated with appropriate sealing oil during installation.

## (2) Fuel Pump Box Size



| No. | Name          | Fuel Pump Packing Size (cm) |
|-----|---------------|-----------------------------|
| 1   | Fuel Pump Box | 30*32*33                    |

### 1.8. 5471860 Fuel Pump Testing Standard and Certificate

Shumatt can provide the factory quality inspection test report of each fuel pump to ensure that each fuel pump delivered meets the engine performance indicators.

| BOTEN                                                                                                                                                                                   |      | 测试报告         |     | 4.05.2019 10:42:09 |   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|--------------|-----|--------------------|---|
| 企业名称: _____<br>电话: _____ 地址: _____<br>传真: _____ 检测人: _____<br>客户地址: _____ 送检单位: _____<br>电话: _____ 客户姓名: _____<br>传真: _____<br>检测项目: _____<br>检测名称: 燃油泵<br>型号-零件号: _____<br>检测地点: _____ |      |              |     |                    |   |
| <b>检测结果</b>                                                                                                                                                                             |      |              |     |                    |   |
| 检测标准: GB1000-1011<br>检测项目: 燃油泵性能                                                                                                                                                        |      |              |     |                    |   |
| ISAK TEST:                                                                                                                                                                              | 38   | 4            | 4.5 | 20.0 ± 1.0         | ✓ |
| Exch:                                                                                                                                                                                   | 38   | 4            | 75% | 20.0 ± 1.0         | ✓ |
| WPRM:                                                                                                                                                                                   | 38   | 42.5 ± 10.5  | 0.3 | 20.0 ± 1.0         | ✗ |
| Max:                                                                                                                                                                                    | 2015 | 218.5 ± 14.4 | 0.3 | 20.0 ± 1.0         | ✓ |
| TL:                                                                                                                                                                                     | 28.4 | 25.0 ± 0.5   | 0.3 | 20.0 ± 1.0         | ✓ |
| LL:                                                                                                                                                                                     | 14.1 | 15.0 ± 0.8   | 0.3 | 20.0 ± 1.0         | ✓ |
| VE:                                                                                                                                                                                     | 42   | 4.0 ± 1.0    | 0.3 | 20.0 ± 1.0         | ✓ |

### 1.9. 5471860 Fuel Pump Warranty Instructions

#### (1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the fuel pump inspection equipment when the fuel pump is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

#### (2) Fuel Pump Warranty Coverage

Within 15 days after customer receives the 5471860 fuel pump, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 5471860 fuel pump has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the fuel pump house has obvious scratches, it can only be repaired and it will be returned as it is if

the product is confirmed to be fault-free.

**⚠ Tips:** For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

### (3) Fuel Pump Out of Warranty Coverage

- ① The warranty period has expired.
- ② Fuel pump failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- ③ Customer disassembles or repairs the fuel pump personally resulting in damage to the Fuel Pump.
- ④ Fuel pump damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Fuel pump failure or fuel pump damage caused by non-fuel pump design, technology, manufacturing, quality, and other issues.
- ⑥ Fuel pump failure due to system pressure exceeding system approved pressure.
- ⑦ Fuel pump failure caused by system voltage exceeding approved voltage.
- ⑧ Fuel pump failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- ⑨ Fuel pump failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- ⑩ Fuel pump failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Fuel pump failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Fuel pump failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Fuel pump failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the Fuel pump connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.


#### 1.10. **5471860** Fuel Pump Manufacturer

**Fuel Pump Manufacturer:** Shenzhen Shumatt Technology Co., Ltd

## 2. **5471860** Fuel Pump Technical Support

### 2.1. **5471860** Fuel Pump Use location

| NO. | Name                         |
|-----|------------------------------|
| A   | Nameplate, Logo, Part Number |



## 2.2. 5471860 Fuel Pump Installation

### (1) 5471860 Fuel Pump Installation Precautions:

- ⚠ The replacement of the fuel pump must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.
- ⚠ Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the fuel pump, the fitting clearance of the fuel pump connection, the installation angle and tightening torque of the fuel pump, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the fuel pump.
- ⚠ When installing the fuel pump on the engine, it is necessary to clean the engine cylinder block, cylinder head and other parts connected to the fuel pump and ensure that they are clean and free of dust, carbon deposits, water, rust spots, etc.
- ⚠ Failure to replace the new sealing ring gasket may lead to: fuel pump deformation, fuel leakage, air leakage, serious damage to the fuel pump, causing the fuel pump to break and cause engine damage.
- ⚠ When installing the fuel pump on the engine, please carefully check that the parts related to the

installation of the fuel pump, such as the fuel pump pressure plate, screws, push rods and other accessories are not deformed, and strictly follow the operating procedures in the engine maintenance manual for installation.

⚠ It is forbidden to expose the fuel pump for a long time in an environment with severe dust pollution and corrosion to iron products.

⚠ It is forbidden to expose the fuel pump for a long time in a strong magnetic field environment.

### 2.3. **5471860 Fuel Pump Not Working Normally**

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump's oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel pump of the vehicle.
- (5) The long-term placement of the fuel pump causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

⚠ Before installing, carefully check whether other components in the common rail system except the fuel pump are damaged to prevent the fuel pump from not working properly after being replaced.

### 2.4. **5471860 Fuel Pump Causes of Being Damaged**

- (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the fuel pump.
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the fuel pump, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. All above reasons can cause damage to the fuel pump.
- (4) The abrasion of the fuel pump produces iron powder and aluminum powder enter the fuel pump and cause damage to the fuel pump.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel pump and causing damage to the fuel pump.
- (6) The fuel pump is damaged due to replacement or adjustment of the relevant parts of the fuel pump. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the fuel pump fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long-time working result in damage to the fuel pump.
- (8) The fuel pump will be damaged naturally at the end of its working life.
- (9) The fuel pump is magnetized (fuel pump parts' magnetic exceeded) causing the fuel pump to not work

properly.

**⚠** Before replacing the fuel pump, please check the engine parts carefully according to the engine maintenance manual to avoid the Fuel Pump being damaged again after replacement.

## 2.5. 5471860 Fuel Pump Technical Support Obtaining Methods

(1) Fuel pump technical file, visit <http://shumatt.com> to get the technical file.

(2) Fuel pump technical videos

**YouTube:** [https://www.youtube.com/channel/UCByvYBx7VjV\\_mAfxh\\_Hu-aw](https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw) to get the technical videos, constantly follow can get more information.

**Shumatt:** Visit <http://shumatt.com> to get the technical videos.

(3) Fuel pump information query software

Truck Book Parts EPC APP, Android/Apple App Store download and install, visit <http://shumatt.com> to get the download and installation tutorial.

(4) Search the fuel pump test data through TruckBook Parts EPC APP.

## 3. 5471860 Fuel Pump Purchase and Delivery

### 3.1. 5471860 Fuel Pump Purchase Payment Term

**Payment Terms:** T/T, PayPal, Alipay, WeChat

**⚠** Please contact our salesmen for specific payment information.

### 3.2. 5471860 Fuel Pump Main Sales Markets

**Fuel Pump Main Sales Markets:** Asia, Europe, North America, South America, Africa etc.

### 3.3. 5471860 Fuel Pump Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

### 3.4. 5471860 Fuel Pump Shipping Ways

**Destination in China Areas:** SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

**Destinations Out of China's Areas:** DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

### 3.5. 5471860 Fuel Pump Lead Time

**Lead Time:** Send out within 3 – 7 working days after receiving payment (ExceXPI for special products and special cases) .

### 3.6. 5471860 Fuel Pump Logistics Time for Destination Out of China's Areas

**DHL Logistics Time:**

| Country or Region of Departure | Hong Kong, China | Other Countries or Regions of Asia | Australia and New Zealand | Europe | America   | Other Countries |
|--------------------------------|------------------|------------------------------------|---------------------------|--------|-----------|-----------------|
| China's Mainland               | 7 Days           | 7 Days                             | 8 Days                    | 8 Days | 8-12 Days | 7-10 Days       |

**UPS Logistics Time: Country or Region of Departure: China's Mainland**

| Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time |
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| Japan                  | 3 Days                 | UK                     | 5-7Days                | EgyXPI                 | 5-7 Days               |
| Turkey                 | 5-7 Days               | Singapore              | 3 Days                 | Switzerland            | 5-7 Days               |
| Bahrain                | 5-7 Days               | Latvia                 | 7-10 Days              | New Zealand            | 7-10 Days              |
| Sri Lanka              | 5-7 Days               | Thailand               | 3 Days                 | Austria                | 5-7 Days               |
| Romania                | 5-7 Days               | Vietnam                | 3-5 Days               | Estonia                | 5-7 Days               |
| Malaysia               | 3-5 Days               | Israel                 | 5-7 Days               | Mexico                 | 7-10 Days              |
| France                 | 5-7 Days               | America                | 5-7 Days               | United Arab Emirates   | 5-7 Days               |
| Italy                  | 5-7 Days               | Netherlands            | 5-7 Days               | Bengal                 | 7-10 Days              |
| Lebanon                | 5-7 Days               | Philippine             | 3-5 Days               | Greece                 | 7-10 Days              |
| South Korea            | 3 Days                 | Spain                  | 5-7 Days               | Myanmar                | 5-7 Days               |
| Canada                 | 5-7 Days               | Germany                | 5-7 Days               | Saudi Arabia           | 7-10 Days              |
| Portugal               | 5-7 Days               | Australia              | 5-7 Days               | South Africa           | 7-10 Days              |
| Denmark                | 5-7 Days               | Belgium                | 5-7 Days               | Ukraine                | 7-10 Days              |
| India                  | 7-10 Days              | Qatar                  | 7-10 Days              | Poland                 | 5-7 Days               |
| Indonesia              | 3-5 Days               | Morocco                | 7-10 Days              | Pakistan               | 7-10 Days              |
| Kuwait                 | 7-10 Days              | /                      | /                      | /                      | /                      |

**⚠ The logistics time is for reference only and is subject to the actual arrival.**

### 3.7. 5471860 Fuel Pump Packing

**Domestic Express Packaging:** Usually wrapped in waterproof scotch tape, such as picture No. 1.

**International Express Packaging:** Wrapped with waterproof yellow tape after wrapping the black protective film, such as picture No. 2.

**Pallet Shipping:** Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

**⚠ The packing tray is made of plastic and can be recycled.**

**⚠ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.**


**⚠ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.**



Pic No. 1

**Domestic express packaging:**

Wrapped with Transparent tape



Pic No. 2

**International express packaging:**

Wrapped with yellow tape after wrapping black protective film



Pic No. 3

**Pallet shipment:** Use pallets that meet export requirements and wrap with white plastic wrap and tie.**4. 5471860 Fuel Pump Storage Standard****(1) Choose a Suitable Storage Place**

The warehouse and cargo yard where the fuel pump is stored should be keXPI clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salt, and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

**(2) Strict Requirements of Warehousing**

Strict inspections should be carried out when the fuel pumps are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ashes, and other dirt, remove the rust and do anti-rust treatment in time. Packaged fuel pumps must be protected from damage.

**(3) Keep The Warehouse Dry And Preventing Moisture**

The relative humidity is usually below 70% for the fuel pumps placed in the room, and the corrosion of the fuel pumps is significantly reduced.

Fuel pumps must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

#### **(4) Stack Properly**

After the fuel pump is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the fuel pump from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the fuel pump package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.



**It is forbidden to leave the fuel pump exposed in the air for a long time.**



**It is forbidden to store acids, alkalis, salts, and other substances together with the fuel pump.**



**The unpacked fuel pump must be rust-proof during secondary storage.**

### **5. Company Information**



#### **5.1. Company Introduction**

**Chinese Name:** 深圳市舒马特科技有限公司

**English Name:** Shenzhen Shumatt Technology Co., Ltd



**Mob Phone/WeChat:** +86-13410541523



**HK Telephone:** +852-67653519



**Telephone:** +86-755-23215133

Mob/Whatsapp: +86 13410541523

Email : [ruby@shumatt.com](mailto:ruby@shumatt.com)

© 2025 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133

Website : [www.shumatt.com](http://www.shumatt.com)

 **Email:** [ruby@shumatt.com](mailto:ruby@shumatt.com)

 **Website:** [www.shumatt.com](http://www.shumatt.com)

 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

 **Shenzhen Office:** Exit C, Qiao Touxu Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

 **After-sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: [1.9. 5471860 Fuel Pump Warranty Instructions](#))

## 5.2. Salesmen's Contact Information

| No.                                                                                                    | Name                         | WeChat/WhatsApp  | Email                                                        |
|--------------------------------------------------------------------------------------------------------|------------------------------|------------------|--------------------------------------------------------------|
| 1                                                                                                      | Ruby                         | +86-13410541523  | <a href="mailto:ruby@shumatt.com">ruby@shumatt.com</a>       |
| 2                                                                                                      | Ivy                          | +86-18025299821  | <a href="mailto:sales@shumatt.com">sales@shumatt.com</a>     |
| 3                                                                                                      | Rebecca                      | +86-18025349821  | <a href="mailto:sales01@shumatt.com">sales01@shumatt.com</a> |
| 4                                                                                                      | Janny                        | +86-18028749821  | <a href="mailto:sales02@shumatt.com">sales02@shumatt.com</a> |
| 5                                                                                                      | Sam                          | +86-13316859821  | <a href="mailto:Sales8@shumatt.com">Sales8@shumatt.com</a>   |
| 6                                                                                                      | Natalie                      | +86- 18938945856 | <a href="mailto:sales15@shumatt.com">sales15@shumatt.com</a> |
| 7                                                                                                      | Ada                          | +86-1342286353   | <a href="mailto:sales5@shumatt.com">sales5@shumatt.com</a>   |
| 8                                                                                                      | Hison Li                     | +86-18318811871  | <a href="mailto:web@shumatt.com">web@shumatt.com</a>         |
| 9                                                                                                      | Mecca                        | +86-18938948618  | <a href="mailto:sales11@shumatt.com">sales11@shumatt.com</a> |
| 10                                                                                                     | Eric                         | +86 18319033618  | <a href="mailto:sales3@shumatt.com">sales3@shumatt.com</a>   |
| 11                                                                                                     | Wayne ( Joaquín en español ) | +86-13316959821  | <a href="mailto:wayne@shumatt.com">wayne@shumatt.com</a>     |
| 12                                                                                                     | Sylvia                       | +86 18312499884  | <a href="mailto:sales6@shumatt.com">sales6@shumatt.com</a>   |
| Visit <a href="http://shumatt.com">http://shumatt.com</a> to obtain the latest information of salesmen |                              |                  |                                                              |
| <b>PS:</b> Shumatt's salesmen's emails are all end with <b>@shumatt.com</b>                            |                              |                  |                                                              |

## 6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds, or videos, etc.) provided in “*5471860 Fuel Pump K19 Series Technical File*” belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in “*5471860 Fuel Pump K19 Series Technical File*” in any way. At the same time, any conditions to spread, repost, display the contents of “*5471860 Fuel Pump K19 Series Technical File*” should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use “*5471860 Fuel Pump K19 Series Technical File*” will

violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions.